


Mounting Accessories

DOWEL PIN STOPS


Cat. No.	Price
5055	



This economical stop is designed for use with 'A' or 'B' Series Units on Template Mounting.

ADJUSTABLE STOPS



Description	Cat. No.	Price
A Series	5092	
B Series	5052	



Adjustable Stop has an adjustment screw for quick compensation of various work piece sizes.

ADJUSTABLE END STOPS AND SPACER ASSEMBLY


Description	Cat. No.	Price
A Series	5135	
B Series	5125	



These End Stops are adjustable front-to-back in three positions on Unispacer.

DISAPPEARING PIN STOPS



Description	Cat. No.	Price
A Series	5048	
B Series	5044	



Disappearing Pin Stops are spring-loaded and are used for Edge and End Gaging in progressive operations.

PICK-UP GAGES — FIXED (1/4" WIDTH)


Description	A SERIES		B SERIES	
	Cat. No.	Price	Cat. No.	Price
Gage for 1/2" Dia. & Under	5056		5058	
Replacement Tip for Above	5057-1		5059-1	
Gage for Over 1/2" Dia.	5056		5058	
Replacement Tip for Above	5057-2		5059-2	



Specify hole size when ordering gages. UniPunch stationary Pick-up gages are used to engage previously punched holes. Designed specially for pass-along multiple-hit operations.

PICK-UP GAGES — SPRG. LD. (1/4" WIDTH)

Description	A SERIES		B SERIES	
	Cat. No.	Price	Cat. No.	Price
Gage for 1/2" Dia. & Under	5046		5042	
Replacement Tip for Above	5047-1		5043-1	
Gage for Over 1/2" Dia.	5046		5042	
Replacement Tip for Above	5047-2		5043-2	



Specify hole size when ordering gages. This UniPunch gage is used in operations requiring retractable pick-up pins, such as multiple hit set-ups.